

Let’s Move Again. Spare Parts.

Article No.
LMA601 Green-Black, LMA701 Grey-Black




Spare parts and article numbers.

Brake levers, adjustment screws and brake housing.




Art. No. LMA306
Set 2pcs.

Rubber handle with tube, reflector and end stop.




Art. No. LMA307 (Left)
Art. No. LMA308 (Right)

Bottom tube stoppers.




Art. No. LMA320.
Set Right + Left.

Height adjustment knobs.




Art. No. LMA048.
Set Right + Left.

Mounting set for seat.



Art. No. LM324.
Set Right + Left.


Dome nuts for seat mounting.



Art. No. LM329.
Set 4 pcs.


Spare parts and article numbers.

Seat.




Art. No. LM310.

Unfold hook with mounting screws and spring.




Art. No. LM311.

Linkage arm with reinforcement, screws and hook.




Art. No. LM312 Left.

Linkage arm with reinforcement and screws.




Art. No. LM321 Right.

Brake wire guide inside rear leg.




Art. No. LM313.
Set Right + Left.

Bag holders.




Art. No. LMA319.
Set Right + Left.

Front fork with front fork bearings.




Art. No. LM318.
Set Right + Left.

Front fork bearings.




Art. No. LM322.
Set Right + Left.

Rear wheel bracket with screws.




Art. No. LMA323.
Set Right + Left.

Brake yokes.




Art. No. LMA328.
Set Right + Left.

Wheel with bearings and mounting set.




Art. No. LM317.

Ball bearings for front and rear wheels.




Art. No. LM477.
Set 4 pcs.

Brake wire with spring and pin for left and right side.



Art. No. LMA305.
Set 2 pcs.

Middle screw for folding cross, complete.



Art. No. 0493.


TRUST
CARE